HUDI – MAGNETIC PUZZLE BALL

User guide

Contents: 24 magnetic puzzle pieces
Recommended age: 8+

HOW TO PLAY

Assemble all 24 pieces into a ball. Match the colors at each seam so the pattern continues across the pieces.

- **Correct fit.** The magnets attract, the pieces sit flush, and the colors and pattern line up.
- **Colors differ.** The magnets may still hold the pieces together. Rotate one piece or try a different one until the pattern lines up.
- **Magnets repel.** If the pieces push apart, rotate one piece or try a different one. Do not force the pieces together.

SAFETY WARNINGS

Warning! Not suitable for children under three years. Small parts. Choking hazard. This toy contains strong magnets.

- Keep the puzzle and its pieces out of reach of children under three. Do not put pieces in the mouth or nose.
- Stop using the puzzle if a piece is cracked or damaged, or if a magnet is loose or missing. Do not open the pieces or remove the magnets.
- If you suspect that a magnet has been swallowed or inhaled, seek medical attention immediately.

Hudi Solutions Kft.
Felhévízi utca 22., 1023 Budapest, Hungary
help@hudisolutions.com
hudi.toys

HUDI – MÁGNESES LOGIKAI LABDA

Használati útmutató

A csomag tartalma: 24 mágneses kirakóelem

Ajánlott életkor: 8 éves kortól

A JÁTÉK MENETE

Rakd össze a labdát mind a 24 elemből. Úgy illeszd össze őket, hogy az illesztéseknél egyezzenek a színek, és folytatódjon a minta.

- **Helyes illesztés.** A mágnesek vonzzák egymást, az elemek pontosan illeszkednek, a színek egyeznek, és a minta folytatódik.
- **Eltérő színek.** A mágnesek akkor is összetarthatják az elemeket, ha a színek eltérnek. Fordíts el egy elemet, vagy próbálj másikat, amíg a minta össze nem illik.
- **Mágneses taszítás.** Ha az elemek taszítják egymást, fordíts el egy elemet, vagy próbálj másikat. Ne erőltesd az összeillesztést.

BIZTONSÁGI FIGYELMEZTETÉSEK

Figyelmeztetés! Három év alatti gyermekek számára nem alkalmas. Apró alkatrészek. Fulladásveszély. A játék erős mágneseket tartalmaz.

- Tartsd a kirakót és az elemeit három év alatti gyermekektől elzárva. Az elemeket ne vedd a szádba, és ne tedd az orrodba.
- Ha egy elem megrepedt vagy megsérült, vagy ha egy mágnes meglazult vagy hiányzik, ne használd tovább a játékot. Ne nyisd fel az elemeket, és ne vedd ki a mágneseket.
- Mágnes lenyelésének vagy belélegzésének gyanúja esetén azonnal fordulj orvoshoz.

Hudi Solutions Kft.
1023 Budapest, Felhévízi utca 22., Magyarország
help@hudisolutions.com
hudi.toys